

## REPUESTOS COP 1838

ITEM	DESCRIPTION	PART N°
1	Rot. Chuck Bushing	3115 2064 00
2	Rot. Chuck Bushing	3115 2968 00
3	Bushing	3115 2084 00
4	Bushing	3115 1881 00
5	Piston Guide Rear	3115 1680 00
6	Piston Guide Front	3115 1671 00
7	Coupling	3115 0277 00
8	Liner	3115 2670 00
9	Dome nut	3115 0286 00
10	Washer	3115 0287 00
11	Flushing Head/ Cám de Agua	3115 2120 00
12	Stop Ring Anillo tope	3115 2122 00
13	Rotation chuck compl	3115 1732 81
14	Return accumulator	3115 2615 91
15	Intake accumulator	3115 2696 80
16	Side bolt (central)	3115 1457 00
17	Side bolt	3115 2113 00
18	Shaft only	3115 0821 00
19	Piston	3115 2129 00
20	Damper accumulator	3115 2700 80
21	Front head	3115 2950 00
22	Guide (bronce)	3115 2118 00
23	Driver (pieza de arrastre)	3115 1582 00
24	Damping Piston (Piston amortiguador)	3115 2382 00
25	Damping Piston (Piston amortiguador)	3115 2971 00
26	Shimm 0.1	3115 0297 01
27	Shimm 0.15	3115 0297 02
28	Shimm 0.5	3115 0297 03
29	Test Valve	3115 2196 00
30	Nozzle (1.7mm)	3115 1746 06
31	Diafragma	3115 1822 00
32	Diaphragm	3115 1926 02
33	Valve Complete	3115 0262 00
34	Connection Plate	3115 1938 00
35	Connection Plate	3115 5152 00
36	OMS 160	3115 1010 80
37	Motor de Rotacion	3115 1010 81
38	Gear	3115 0274 00

<b>REPUESTOS PARA VIGA</b>		
<b>ITEM</b>	<b>DESCRIPTION</b>	<b>PART N°</b>
1	Driver de meza (viga)	3128 3052 25
2	Holder	3128 0785 48
3	Holder	3128 0785 49
4	Holder Set	3128 3061 80
5	Holder Set ( holder + sliding p)	3128 3061 81
6	Sliding Piece	3128 3039 30
7	Sliding Piece Gde.	3128 3074 88
8	Support Bushing	3128 3025 53
9	Support Bushing Gde.	3128 3025 61
10	Protection Coil	3128 0225 01
11	Protection Coil	3128 0224 00
12	Inter support	3128 3016 84
13	Profile	3128 0893 00
14	Pulley Wheel	3128 0781 90
15	Pulley Wheel (Polea Completa)	3128 0784 30
16	Hose Drum	3128 0475 10
17	Dowell	3128 3035 27
18	Dowell	3128 3037 03
19	Slide Bar 6250 MM	3128 0458 18
20	Slide Bar 4040MM	3128 0458 01
21	Mesa porta carrete (Hose Drum)	3128 0484 00
22	Mesa Central Móvil (Profile)	3128 0782 58
23	Mesa Porta Perforadora (COP)	3128 3061 74
24	Bolt	3128 3069 55
25	Check Valve	8231 1202 86
26	Overcent Valve	8231 1203 06
27	Expanding Shaft	3125 1982 80
28	Expanding Shaft	3125 4937 80
29	Bushing	9128 7344 00
30	Guide HD	3115 5045 01
31	Piston guide HD	3115 5050 01
32	Piston HD	3115 3635 00
33	Shank Robit 1833T	C038/435mm
34	Diafragma corbata RD	3115 1926 00
35	Diafragma plato RD	3115 1822 00